

HomeAware Basic Receiver Quick Set-Up Guide Item# HA360SSSCK

The HomeAware Smoke & CO transmitter (item# HA360SSSCK) is designed to expand the scope of the HomeAware Main Unit, alerting individuals of certain activity in the home via an audible alarm or strobe light. It will be necessary to link your Basic Receiver to your HomeAware Main Unit.

To link the Smoke & CO transmitter to HomeAware Main Unit, follow steps below:

1. Press SET UP button on the Main Unit. The word LINK will show on the display where the time of day is usually appears. Press ENTER. The word LINK will begin to flash.



2. Press and release the black button located on the back of the Smoke & CO transmitter. The main unit will then say DONE. The receiver's light will flash. The units are now linked together and ready to use.